

(Diag 1)



1. Twist off Black Cap

(Diag 2)



2. Twist on white Tip

3. Put PLUNGER IN Back of Gel Tube. (Diag 2)

---